

LOC⁴⁰ PRECISION

40 YEARS OF HIGH POWER

LOCPRECISION.COM



29mm - 1/4" launch rod

This kit requires CA Glue for assembly.
Bob Smith Thick CA shown - not included.



Glue body tube to base.



Add decal to base. Trim launch lug hole.



Insert shock cord through ring with slot. Feed shock cord end through sewn loop, pull tight. Glue rings on motor tube. Motor block included - use if desired.



Sand centering rings to fit spacer tube. Motor tube should protrude from spacer tube. As well when test fit, protrude from base for motor retention. Glue motor mount in spacer tube.



Insert assembly from top. Align launch lug holes. Glue top plate in place.



Slide fire blanket onto shock cord. Attach recovery. Add decal to top plate. Add decal to body tube.

Fly F or G motors!



150' of NOISE, SMOKE, AND FIRE!

Scan for
product details



LAUNCH

- The motor delay needs to be short, 4 seconds or less.
- Friction fit the motor with masking tape so motor won't pop out at ejection.
- Fold parachute in quarters and zig zag shroud lines inside rolling them up like a burrito.
- Install recovery wadding or included fire blanket. Shove burrito down the Alien's throat, it can hang out slightly.

For product support,
please email us at
support@locprecision.com