

### STEP 5

Cut the launch lug in half at an angle, making them aerodynamic. Find the high point of the airframe between fins. Mark a straight perpendicular line up 10" from the AFT of the airframe. Epoxy one lug 2" up from the AFT of the airframe. Epoxy another at least 8" FWD. Allow to cure.

### STEP 6

Take one end of the shock cord and pass it through the loop of the shock cord mount. Secure it with a double knot. Take the other end of the shock cord and pass it through the eyelet of the plastic nose cone and also secure it with a double knot. Place a SMALL drop of glue on both knots to keep them permanently secured.

### STEP 7

Attach the parachute to the shock cord at a point about 1/3 of the length of the shock cord from the nose cone. To do this, take the chute shroud line loops in one hand and, with the other hand, take the chute and go around the shock cord, passing the chute through the shroud line loops. When the chute is pulled through tightly it will form a knot.

### STEP 8

Lightly sand plastic nose cone with fine sandpaper to remove molding seam line. Also sand airframe and fins to produce a smooth finish.

### FINISH

Spray rocket with primer, sand and repeat until smooth finish is obtained. Spray rocket with paint of choice, let dry. Apply protective clear coat.

### Attention!

This rocket is recommended for low to mid power rocket motors E — J impulse. Depending on your flying field and finished weight, this is a very versatile kit. Always check stability to ensure stable flight; the Center of Gravity (CG) must be forward of the Center of Pressure (CP) in flight ready condition.

Since Yank Aeronautics LLC dba LOC PRECISION cannot control the use of its products once sold, the buyer assumes all risks and liabilities there from, and accepts and uses LOC Precision products on these conditions.

© YANK AERONAUTICS LLC. dba LOC PRECISION ALL RIGHTS RESERVED



## Nuke Pro Maxx™

FLYING MODEL ROCKET KIT



# E-J

Capable Impulse

DIAMETER 2.26"  
HEIGHT 39.5"  
WEIGHT 16oz

### Featuring:

- 2.26" Pre-Slotted Airframe
- 24" Rip-Stop Nylon Parachute
- Shock Cord
- 38mm MMT
- Launch Lug
- Hardware



435A Factory Street, Plymouth, WI 53073  
920.892.0557  
LOCprecision.com

PK-5  
HAND MADE  
IN THE  
USA



# LOC 2"

## NUKE PRO MAXX

- 22" Slotted Booster
- 10" Payload Section, coupler, bulkhead
- Polypropylene Nose Cone
- 24" Parachute
- SCM1 Shock Cord Mount
- Tubular Nylon shock cord
- 11" 38mm Motor Tube
- 1/8" Fin Set
- 3 1/4" Centering Rings
- 1/4" Launch Lug

### Step 4 — Shock Cord Mount Instructions

LOC/PRECISION'S Shock Cord Mount is easy to make and install, yet is very strong! This mounting system makes shock cord attachment quick and easy. Follow instructions carefully!



1. Take the length of 2' Kevlar cord and at its center make a 1" long loop knot and pull it tight. Make a knot a 1/4" away from the end of EACH of the two loose ends.
2. Cut a piece of masking tape 1/4" wide by 1 1/4" long. This is centered crosswise just ahead of the two knots.
3. Carefully place the two knotted loose ends of the Shock Cord Mount, with tape attached, inside the top of airframe tube so that the 1" long loop knot is protruding out about 1" from the airframe tube's edge. Making sure there is enough room for the cone should to fit down the airframe! Using a small piece of wooden dowel, press the masking tape down firmly around the inside of the airframe tubing. The masking tape will keep the Shock Cord Mount in place while gluing. Using a small piece of wooden dowel, press the masking tape down firmly around the inside of the airframe tubing.
4. Place a generous bead of glue over the knotted ends and length of masking tape. Spread the glue around until they are completely covered and place the airframe in a horizontal position to dry. **REPEAT STEP 4 UNTIL A SMOOTH GLUE LAYER IS ACHIEVED OVER THE MASKING TAPE AND KNOTTED ENDS.**

**Due to the high thrust motors that can be flown in this rocket, epoxy is recommended!**

**Before beginning construction**, read over instructions to become familiar with the proper construction steps. **TEST FIT ALL PARTS!** Light sanding may be necessary to obtain proper fit.

### STEP 1

Rough sand the motor tube to ensure proper adhesion OR remove the outer glassine wrap. Slide the one ring onto the motor tube so the tube is 1/8" exposed from the ring. OR measure out where the FWD of the fin tab will be, some choose to sandwich their rings to the fin tabs. Insert other ring on other end of motor tube so 1/8" of the motor tube protrudes. Tack rings into place with epoxy, allow to cure. Epoxy fillet both sides where the ring meets the motor tube. Allow to cure.

### STEP 2

Slather epoxy in the AFT of the airframe between each fin slot. Insert motor mount assembly up the airframe. Slide all the way up the airframe until the MMT is flush or slightly recessed with the AFT of the airframe. Once cured apply a small layer to the AFT of the AFT ring. Allow to cure.



### STEP 3

Reposition airframe laying down. Apply a generous bead of epoxy to the root edge of one fin and insert in the fin slot. Allow to cure before moving onto the next fin. When all fins are epoxied in place, apply an external fillet to each fin to airframe joint.

**CROSS SECTION OF CENTERING RINGS/ MOTOR MOUNT TUBE ASSEMBLY IN MAIN AIRFRAME.**

